

# Yaesu FT70DR Personal Notes (KG6LIN)

Last update: May 7, 2019

Power Cable from Amazon:

[https://www.amazon.com/gp/product/B000LFVFJE/ref=ppx\\_od\\_dt\\_b\\_asin\\_title\\_s00?ie=UTF8&psc=1](https://www.amazon.com/gp/product/B000LFVFJE/ref=ppx_od_dt_b_asin_title_s00?ie=UTF8&psc=1) ~\$5.00

Attach power cable to any 1.5Amp (or more) 12V source. ID of Plug is +, outside is - polarity.

Power Cable from Yaesu: <https://www.yaesu.com/AccessoryImages/E-DC-6.jpg> ~\$20

Head Set from Amazon:

[https://www.amazon.com/gp/product/B00CQH97R2/ref=ppx\\_od\\_dt\\_b\\_asin\\_title\\_s00?ie=UTF8&psc=1](https://www.amazon.com/gp/product/B00CQH97R2/ref=ppx_od_dt_b_asin_title_s00?ie=UTF8&psc=1) ~\$9.00

Modify by opening mic assembly (turn tie clasp and unscrew Philips screw). Then drill or file out small hole where mic sits. Without the hole mic sounds very muffled. Remove mic when drilling or filing. Reassemble be careful not to pinch wires.

Head Set from Yaesu: <https://www.yaesu.com/AccessoryImages/SSM-57A.jpg> ~\$30

Good video: <https://www.youtube.com/watch?v=10WMZIIhTto>

Good Blog: <https://wb4son.com/wpblog/?p=3406> (See reply)

[www.photocrazy.com/HAM/FCList.pdf](http://www.photocrazy.com/HAM/FCList.pdf) (FCS list with FCS Corrections - needs frequent updating)

[https://www.pistar.uk/fcs\\_reflectors.php](https://www.pistar.uk/fcs_reflectors.php) (Latest FCS List without Corrections)

<https://forum.pistar.uk/> (Good forum for answers)

1. Set FT10 to WIRES mode: PressF PressAMS Displays WIRES

2. DialTo\* \_\_\_\_ EnterYSF/FCS# PressAMS (DiDiDiDi) PressPTT to talk

If you make an error, power down, wait 10 sec, power up and go to 1.

Note: PressAMS after entering YSF/FCS# only if there is no QSO

Note: Use FCS# from 1st column at: [www.photocrazy.com/HAM/FCList.pdf](http://www.photocrazy.com/HAM/FCList.pdf)

To SAVE a room while at Cn; Click and hold 1, 2, 3, 4 or 5 for C1, C2, C3, C4, C5

Not every YSF/FCS# is saved when HT is turned OFF/ON

To CONNECT a room go to C1, 2, 3, 4 or 5 and Press and hold AMS ~.5sec CONNECT

To DISCONNECT go to Cn and Press and hold BAND until DISCONNECT

Disconnect only works if there is no QSO going on.

If QSO is going on, use Config Screen and call up any other station

YSF	FCS	Peanut	*Cn Entry	Mem	Name
13953	FCS00290		00139	C1	AmericaLink
62554	FCS00334		00177	C2	TexasNexus
64230	FCS00285		00137	C3	America-RC
	FCS00358		00184	C4	AlabamaLink
	FCS00299		00142	C5	ECHO
	FCS00390		00197		AmericaLink
	FCS00422		00224		America-RC
	FCS00323		00166		MNWis
74154		DMR4445		NO	DMR
		XRF021B		NO	Pegasus Germany